① Factory Default

Factory Default

② Version Information

Version

③ Setting Codes

ON

OFF

④ Interfaces Mode

RS232

USB

⑤ Scanning Mode

Automatic Successive Scanning

Automatic Induction Scanning

OFF Automatic Scanning

Automatic Flashing

Single scan only

⑥ Keyboard Language Selection

USA

Germany

France

⑦ Buzzer

ON

OFF

⑧ Prefixs&Suffixs and Line Feed Settings

Add Prefix

Add suffixs

Enter

Line Feed

Cancel Enter