2D Barcode Scanner User's Manual

V5.1

This user's manual is designed for 2D barcode scanner.For detailed usage information,please download the complete user's manual from our website or from our authorized distributors.

Note: The setting code is a functional bar code, please do not scan it when it is not necessary, please scan the bar code on the product.

▼ Factory Default Setting

Factory Default Setting

Note:Factory default settings are marked with an asterisk"*"in this manual.

Interface

▼ USB

Connect the computer, scan the "USB Keyboard" barcode, barcode scanner is USB Keyboard model, if you want to set USB-COM, should install the USB-COM driver, and set baud rate: 115200, data bit:8, Parity: None, stop bit: 1.

* USB Keyboard

USB COM

▼ USB HID

USB HID

▼ RS232

Connect RS232 interface, scan the "RS232" bar code, the serial port related setting is: baud rate :115200, data bit:8, Parity: None, stop bit: 1.

RS232

▼ All codes

All 1D code on

All 1D code off

All 2D code on

All 2D code off

▼ QR URL code setting

* URL Off

URL On

▼ Decode Beeper

Low

Medium

* High

Off

▼ Safe mode

* Setting code function Off

Setting code function On

▼ Chinese output format

GBK (output in Notepad, EXCEL, WPS)

UNICODE (output in word)

▼ Same code delay time

100ms

* 350ms

▼ Terminal setting

* Enable CR

Disable CR

Enable CR+LF

Disable CR+LF

▼ Keyboard layout

* USA

SPAIN

FRANCE

GERMANY

ITALY

CZECH

RUSSIA

CROATIA

TUYKEY Q

Serial port setting

▼ Baud rate

2400

4800

9600

19200

38400

57600

* 115200