Firstly setting the channel for terminal, and waiting for the scanner to response;

Then setting the channel for scanner, make sure this channel is same as the terminal's.

The following is the channel point corresponding to the setting code for scanner:

Channel	Point (M)	Setting Code	Channel	Point (M)	Setting Code
0	433.092	034000	10	442.092	034010
1	430.092	034001	11	445.092	034011
2	427.092	034002	12	448.092	034012
3	424.092	034003	13	451.092	034013
4	421.092	034004	14	454.092	034014
5	418.092	034005	15	457.092	034015
6	415.092	034006	16	460.092	034016
7	412.092	034007	17	463.092	034017
8	436.092	034008	18	466.092	034018
9	439.092	034009	19	469.092	034019
			20	472.092	034020

For terminal: all the channels are same as scanner's, only the first four numbers are "0390".Such as the setting code of channel 0 is 039000, setting code of channel 18 will be 039018. The following are some setting codes for scanner and terminal:

Scanner Channel 0

034000

Scanner Channel 7

034007

Scanner Channel 20

034020

Terminal Channel 0

039000

Terminal Channel 7

039007

Terminal Channel 20

039020

1.7 Inventory Options

All the inventory options will be valid in inventory mode, will be generated a error tone in other modes.

（1）Checking the total number of inventory data

Scanning "032100"， the total number of inventory data will be showed on the terminal.

（2）Uploading inventory data

Scanning "032200", all the scanning data will be uploaded on the terminal.

Checking Total Number

032100

Uploading the Inventory Data

032200

（3）Inventory auto clear on and off

Inventory data mode can set to clear memory automatically after uploading.

Auto Clear

032301

No Auto Clear

032300