57600

115200

Barcode Setting

Enable Code 39

Disable Code 39

Enable UPC-A

Disable UPC-A

Enable UPC-E

Disable UPC-E

Enable EAN-13

Disable EAN-13

Enable EAN-8

Disable EAN-8

Enable Code-93

Disable Code-93

Enable Code-128

Disable Code-128

Enable Codabar

Disable Codabar

Enable Interleaved 2 of 5

Disable Interleaved 2 of 5

Enable Industrial 25

Disable Industrial 25

Enable MSI

Disbale MSI

Enable Plessey

Disable Plessey

Enable Code-11

Disable Code-11

Enable Matrix 2 of 5

Disable Matrix 2 of 5

Enable Postcode 25

Disable Postcode 25

Enable Aviation 25

Disable Aviation 25

Enable GS1 Omnidirectional

Disable GS1 Omnidirectional

Enable GS1 Limited

Disable GS1 Limited

1D
Laser Barcode Scanner
User Manual

Version

This manual is simplified ,for detailed manual information please download the completed user manual from our website or obtain it from our distributor.

Factory Default

Note:Default interface:USB-HID

Setting Procedure:
Scan required bar codes

Example: Factory default,USB-HID,add suffix "Enter"ect barcode as below

1 Factory Default

2 Enter

Interfaces

USB-HID

USB-COM

PS2

RS232

Scan Mode

Manual

Continous

Automatic Flashing

Auto-Induction

ON

OFF

Buzzer

OFF

ON

Low

High

Image Inverted

Direct

Reverse

Keyboard Language

USA

UK

French

Suffix Setting

Enter

Enter&Line feed

Cancel

USB-COM、RS232 Baud Rate Setting

4800

9600

19200

38400