System Settings



Restore Wireless Defaults



Version

Data Format



GB2312



Unicode(UTF-8)

Note: This product supports wireless 2.4G receiver and wired USB interface to directly output GB2312 or Unicode encoding

Data Transfer Mode



Synchronous Mode*



Storage Mode

Data Control



Upload All Data



Total Data Uploaded



Clear All Data

Wireless 2.4G Pairing

Wireless 2.4G mode supports Windows, Mac OS, Linux, Unix, Android and other systems.

Step 1: Scan the "Wireless 2.4G Mode" setting code;
After the setting is completed, the receiver that has been paired last time will be prioritized by default.

Wireless 2.4G Mode

Step 2: Scan the "One-click Pairing" setting code;
The blue light of the bar code flashes quickly and enters the 2.4G pairing state.

One-click Pairing

Step 3: Plug the receiver into the host (within 1 minute),hear a "Di", and the blue LED2 stays on. The connection is paired successfully.

Bluetooth HID Pairing

Wireless Bluetooth HID supports Windows, Mac OS, IOS, Android and other systems.

Step 1: Scan the "Bluetooth HID Mode" .
After the setting is completed, the Bluetooth device that was paired last time is prioritized by default.

Bluetooth HID Mode

Step 2: Scan the "One-click pairing" setting code;
The blue LED1 and blue LED2 of the scanner flash alternately and quickly, and enter the Bluetooth HID pairing state.

One-click pairing

Step 3: Turn on Bluetooth in the host device and search for the "BarCode Scanner HID" device, and then click on the device. Until you hear a "Di", the Blue LED2 stays on. The connection is successfully paired.

Note: After pressing the key for 8 seconds, you can quickly enter the Bluetooth hid pairing status.

Bluetooth SPP/BLE Pairing

Wireless Bluetooth spp / ble supports using Bluetooth serial port to connect windows, Mac OS, IOS, Android and other systems.

Step 1: After scanning "Bluetooth SPP Mode", the blue LED2 flashes quickly. (Or after scanning "Bluetooth BLE Mode", the blue LED1 and LED2 flash quickly and synchronously.)



Bluetooth SPP Mode



Bluetooth BLE Mode

Step 2: Use the serial port transparent transmission tool on the host device, search for the device "BarCode Scanner SPP" or "BarCode Scanner BLE", and then click the device until you hear a "Di" and the blue LED2 is on. The connection is paired successfully.

Long press for 8 seconds

Press and hold for 8 seconds to enter the Bluetooth pairing status setting.



Enable*



Disable

IOS HID virtual keyboard

When using Bluetooth HID mode to connect to the IOS, You can set a quick double-click to show or hide the IOS virtual keyboard.



Enable*



Disable