⑥ Keyboard Language Selection


USA


Germany


France

⑦ Buzzer


ON


OFF

⑧ Prefixs&Suffixs and Line Feed Settings


Add Prefix


Add suffixs


Enter


Line Feed


Cancel Enter

① Factory Default


Factory Default

② Version Information


Version

③ Setting Codes


ON


OFF

④ Interfaces Mode


RS232


USB

⑤ Scanning Mode


Automatic Successive Scanning


Automatic Induction Scanning


OFF Automatic Scanning


Automatic Flashing


Single scan only