
Product appearance



Setting Sequence

Enter Mode → Setting Code → Exit Mode

Setting Code

Enter Setting

Exit Setting

Wireless Default Configuration

Scan Continuously

Scan Manually (Default)

Storage Upload

Clear data

Real TimeUpload (Default)

Display Number of Storage

Automatic matching (Default)

Upload Data

Channel 1

Channel 3

Channel 2

Hibernate For 60S

Not Hibernate